

USE AND MAINTENANCE MANUAL



PRECISION AIR CONDITIONING UNIT
WITH DIRECT EXPANSION

ED "MILLENNIUM"

TABLE OF CONTENTS

1	INTRODUCTION	Pag.2
1.1	Manual content	Pag. 2
1.2	Safety marks	Pag. 2
1.3	Referring standards	Pag. 2
1.4	Warranty	Pag. 3
1.5	Readers of the Manual	Pag. 3
2	MAIN SAFETY RULES	Pag. 3
2.1	Main warnings	Pag. 3
2.2	Allowed use	Pag. 3
2.3	Forbidden use	Pag. 3
2.4	Dangerous areas	Pag. 4
3	GENERAL DESCRIPTION	Pag. 4
3.1	Unit description.....	Pag. 4
3.2	Main components	Pag. 7
3.2.1	Cooling circuits	Pag. 10
3.3	Specification	Pag. 14
3.4	Dimensional drawings	Pag. 14
3.5	Accessories	Pag. 15
4	INSTALLATION	Pag. 17
4.1	Identification tag	Pag. 17
4.2	Reception and inspection	Pag. 17
4.3	Handling	Pag. 18
4.4	Arrangements and placing	Pag. 19
4.5	Cooling connections (ED.A, ED.M)	Pag. 20
4.6	Condenser hydraulic connections (ED.W)	Pag. 26
4.7	Condensate drain connection	Pag. 26
4.8	Humidifier connections	Pag. 26
4.9	Fresh air intake connections	Pag. 28
4.10	Electric connections	Pag. 28
4.10.1	Power supply connection	Pag. 29
4.10.2	Remote control connection	Pag. 29
4.10.3	Warning in case of connection to the terminal board when optional "TE" is installed	Pag. 30
4.10.4	Condenser (ED.A) or motor-condenser (ED.M) connections	Pag. 31
4.11	System vacuum and charge execution (ED.A, ED.M)	Pag. 31
4.11.1	General warnings	Pag. 31
4.11.2	Vacuum execution	Pag. 32
4.11.3	Refrigerant charge execution	Pag. 33
5	OPERATION	Pag. 35
5.1	First startup	Pag. 35
5.1.1	Cooling circuit (ED.A, ED.M)	Pag. 35
5.1.2	Hydraulic circuit	Pag. 35
5.1.3	Startup	Pag. 35
5.1.4	Setup	Pag. 36
5.1.5	Microprocessor setting	Pag. 37
5.1.6	Steam production setting (unit with humidifier)	Pag. 37
5.2	Fault alarm and display system.....	Pag. 38
5.3	Troubleshooting	Pag. 39
5.4	Routine maintenance	Pag. 41
6	DISMANTLING	Pag. 41
	AIR CONDENSER	Pag. 42
	STEAM HUMIDIFIER	Pag. 49
	ATTACHMENTS	

The manufacturer reserves the right to modify this manual without any prior notice.

1 - INTRODUCTION

1.1 Manual content

The present handbook, originally written in Italian, was completed in compliance with the "Machinery Directive". It contains all the necessary information for carrying out without any risk transportation, installation, startup, operation, setting, maintenance and dismantling of the air conditioning unit of ED Millennium series.

Should you have any doubt on the correct understanding of these instructions, please contact the Manufacturer in order to get further explanations.

1.2 Safety marks

The following safety marks are used in this manual to draw attention to all useful information in order to avoid any dangerous situation which could be unsafe and harmful for people, could damage equipment and environment besides breaking the unit.



It means operation and behaviour not allowed.



It means danger or risk to people, things or environment.



It means an electrical danger.



It means a warning about important functions or useful information. Pay the maximum attention to the paragraphs marked with this symbol.

1.3 Referring standards

The units of the 'ED' series are designed and manufactured in compliance with the relevant European Directives and in particular, they meet the "Essential Safety Requirements" as set out in the European Directive 89/392/CEE, and further amendments, as attested by the CE mark that is on each unit.

As a matter of fact, the units are certified by the manufacturer and are provided together with the CE Declaration of Conformity which is attached to the present manual.

Where applicable, the units mentioned in this handbook are in conformity with the directive 97/23/CE (PED), concerning the pressure devices.

1.4 Warranty

The manufacturer warrants the Air Conditioning Units according to what stated on his general sales terms or according to what else explicitly agreed.

The Manufacturer Warranty is void in case the guidance of this manual has not been carefully respected.

The manufacturer refuses all responsibility for any damage to people, animals, things or environment, caused by incorrect installation, maintenance or setting or misuse of the machine. It is considered as "misuse" of the machine any use not explicitly allowed in this manual.



Warning: on the first startup, duly fill in the relevant report attached to this manual and send a copy to Emicon A.C. (Customer Service), in order to make the warranty valid.


1.5 Readers of the Manual




This manual and all its attachments are supplied with the described unit. The manual must be kept by the machine's owner in a proper place. To this end, a plastic bag where to store the manual has been placed inside the machine so that it can be always easily accessible for consultation and at the same time, it can be preserved in a good state.

In case the manual is lost or deteriorated, a new copy must be requested directly to the manufacturer.

2 - MAIN SAFETY RULES

2.1 General warnings

 Read carefully the whole handbook before performing any operation on the unit. Only qualified and trained technicians must perform any operation on the machine.

 Do not touch the machine if with bare feet or with humid or wet parts of the body.
 Do not perform any cleaning operation before the main switch is "OFF" and power line disconnected.
 Do not spread, leave unattended or to the reach of children any packaging material (carton box, staples, plastic bags, etc.) as they may be a source of danger.

2.2 Allowed use

The machine has been designed and produced for air conditioning of technology centres and therefore it must be used only for this purpose, according to its performing features. All different uses are not allowed and disclaim all manufacturer's responsibility for damages caused to environment, people, animals and properties.

2.3 Forbidden use

Do not use the machine:

- Ø for other use than that described in paragraph 2.2;
- Ø when it is exposed to rainfall;
- Ø in atmosphere with high risk of fire or explosion;
- Ø in spaces with corrosive atmosphere.



Any operation on the unit must be carried out in compliance with local technical standards.

2.4 Dangerous areas

The machine is closed by case panels, at the exception of the upper part on some models. The dangerous parts inside the unit are not accessible from outside.



Only qualified and trained personnel is allowed to remove the covering panels because inside the unit there are parts with high risk of electric shock, areas with high temperature and working mechanical components.



If the machine is supplied with the cooling circuit already charged with pressure gas, it is necessary to pay the maximum attention in order to avoid accidental release of the gas in the atmosphere.

3 - GENERAL DESCRIPTION

3.1 Unit description

The precision air conditioning units with direct expansion coil of the ED Millennium series have been designed for being used in technology centres, computer processing centres, telecom applications and whenever special thermic and humidity conditions are required.

The machines have been conceived for operating with ecological gas R407C (K version), R134A (Ka version), R410A (Kc version) and with refrigerant R22 (without any indication of the kind of gas).

The machines are suitable only for internal installation.

All units are electrically tested at the factory (ED.W units undergo a complete operational test).

The units are supplied with nitrogen pressure cooling circuit (ED.W series is supplied with refrigerant charge) and with anti-freezing oil in the compressor (at the exception of ED.M series).

The available versions are:


ED...A	Indoor unit to be connected to a remote condenser;
ED...W	Indoor packaged unit with built-in water cooled condenser;
ED...M	Indoor unit to be connected to a remote condensing unit (indoor unit without compressors)

The machines are available in different configurations according to the air intake and discharge:


U:	Air intake from the front and upflow air discharge;
V:	Air intake from the bottom and upflow air discharge;
B:	Air intake from the back and upflow air discharge;
D:	Air intake from the top and downflow air discharge.

The different unit models of the ED Millennium series are marked with initials, whose interpreting key is shown in the scheme on page 5.

Interpreting key for the initials used to mark the air conditioning units of the ED Millennium series




As shown in the scheme in the previous page, the air conditioning units are classified according to the transfer path of the air inside the conditioning machine before being discharged into the working room at the desired temperature. The following pictures show the four possible different configurations, according to the air distribution system.



Configuration U: air intake from the front and upflow air discharge

Configuration B: air intake from the back and upflow air discharge



Configuration V: air intake from the bottom and upflow air discharge

Configuration D: air intake from the top and downflow air discharge

3.2 Main components


The units of ED Millennium series are made of the following main components:

- Ø The housing is made of galvanized steel sections covered with epoxy painted steel plate panels. The panels are provided with internal polyurethane plate covers to reduce noise.
- Ø ED.A and ED.W versions are equipped with high efficiency scroll compressors, installed on rubber vibration dampers with thermal protection.
- Ø Centrifugal fans directly coupled with low fan speed regulation.
- Ø Direct expansion cooling coil with copper pipes and aluminium fins .
- Ø Stainless steel drain pan.
- Ø Regenerable air filters with efficiency grade F4.
- Ø Cooling circuit composed of all required components for a correct and reliable unit operation, as described in par. 3.2.1.
- Ø The electric board in compliance with CE regulations and provided with main disconnecting switch; thermal and amperometric protections, contactors, auxiliary low voltage circuit, terminal board and control by microprocessor.


ED - D (L series)

Key

- 1) Electric board
- 2) Fan
- 3) Direct expansion coil
- 4) Humidifier (optional)
- 5) Compressor (except for ED.M)
- 6) Liquid receiver (ED.A only)
- 7) Water condenser (ED.W only)
- 8) Microprocessor display
- 9) Heating coil (optional)
- 10) Air filters



Picture 1




ED - D (M series)


ED - U (L series)

Key

- 1) Electric board
- 2) Fan
- 3) Direct expansion coil
- 4) Humidifier (optional)
- 5) Compressor (except for ED.M)
- 6) Liquid receiver (ED.A only)
- 7) Water condenser (ED.W only)
- 8) Microprocessor display
- 9) Heating coil (optional)
- 10) Air filters




Picture 2




ED - U (M series)

3.2.1 Cooling circuits


Air conditioning unit with remote condenser (ED.A)



Air conditioning unit with water condenser (ED.W)



Air conditioning unit with remote condensing unit (ED.M)



Cooling circuits key

AC	AIR HEAT EXCHANGER	PDIO	OIL GAUGE	VE	EXPANSION VESSEL
AD	AIR DISCHARGE VALVE	PDSO	OIL LEVEL PRESSOSTATIC VALVE	VP	EVAPORATOR
AV	VIBRATION DAMPER	PDSW	DIFFERENTIAL WATER SWITCH	VT	THERMOSTATIC EXPANSION VALVE
CM	COMPRESSOR	PIH	HIGH PRESSURE GAUGE	WC	WATER COIL
CO	CONDENSER	PIL	LOW PRESSURE GAUGE	WD	WATER CHARGE AND DISCHARGE VALVE
CT	CONDUCTIVITY PROBE	PIW	WATER VALVE	WE	WATER EXCHANGER
EF	FAN	PRV	OVERPRESSURE DISCHARGE DEVICE	WF	WATER FILTER
EHA	ANTIFREEZE HEATER	PRW	SAFETY WATER FLOW SWITCH	WP	WATER PUMP
EHC	CRANK-CASE HEATER	PSH	HIGH PRESSURE SWITCH	WT	WATER BUFFER TANK
EV	SOLENOID VALVE	PSL	LOW PRESSURE SWITCH	BG	HOT GAS COIL
FSR	FAN SPEED REGULATOR	PT	PRESSURE TRANSDUCER	YVCA	HUMIDIFIER FILL VALVE
FWV	4-WAY VALVE	RE	ELECTRIC HEATER	YVSA	HUMIDIFIER DRAIN VALVE
H	HUMIDIFIER	RV	MODULATING VALVE		
HR	HEAT RECOVERY	SA	LIQUID SEPARATOR		
HT	HUMIDITY PROBE	SFF	FREON-FREON HEAT EXCHANGER		
LF	DEHYDRATING FILTER	SFO	FREON-OIL HEAT EXCHANGER		
LS	SIGHT GLASS	SL	NOISE LEVEL REDUCER		
LT	LIQUID RECEIVER	SO	OIL SEPARATOR		
NR	NON-RETURN VALVE	SV	SHUT-OFF VALVE		
OF	OIL FILTER	TS	SAFETY THERMOSTATIC VALVE		
OLR	OIL LEVEL REGULATOR	TT	TEMPERATURE PROBE		
OT	OIL RESERVE	TWV	3-WAY VALVE		


3.3 Specification

The main technical features of the units are shown in the attachments.

3.4 Dimensional drawings

Table 1 shows the dimensions of the different models of air conditioning units with reference to Picture 3.

Table 2 shows the available unit models for each steel frame size of the series.



Picture 3

Table 1

STEEL FRAME SIZE	L1	L2	L3	M1	M2	M3	M4	M5	M6
A	490	640	940	1230	1530	1730	1990	2390	2950
B	1800			1975	1995				
U/V/D version	C	565		815		815			
B version	D	615		965		965			

Table 2

STEEL FRAME SIZE		L1	L2	L3	M1	M2	M3	M4	M5	M6	
MODELS	ONE-CIRCUIT	61	101	151	221				581		
		81	121	171	241	321	351	471	651		
		91	141	201	251	361	431	521	721		
					291	451	531	601	821		
					301						
					341						
	TWO-CIRCUIT				172	202	302	412	482	542	762
					192	232	362	452	532	622	892
						272	442	492	572	682	1002
						342			602	842	1102

3.5 Accessories

The units can be equipped with a wide range of optional accessories, the main of which are described in the following list:

AA: Flooding probe sensitive to the water present under the floor.

AE: Power supply different from the nominal power.

AF: Clogged filters alarm.

AL: Smoke alarm.

AM: Soundproofing baffles on air outlet.

AR: Soundproofing baffles on air inlet.

B: The base frame in welded steel tubes is available for every unit model and its height is adjustable between 140 and 580 mm.

BC: Hot water coil with three-way valve and modulating actuator.

BG: Hot gas coil.

BN: Base frame equipped with conveyor (min H 380mm - max 550mm)

BS: Base frame provided with On/off motorised damper for D version.

CI: Soundproofing covering on compressor (not available for steel frame size L1).

CS: Compressor inrush counter.

DH: Dehumidification control system without H.

ETF: Electronic tangential fans (for steel frame sizes from M1 to M5 - not available for M3 D).

ETF 1M: Electronic tangential fans (for steel frame size M5) with higher available pressure.

F5,F6,F7a: Different efficiency grades of air filtration (thickness 50-100mm)

F7b, F9: Different efficiency grades of air filtration (thickness 300mm) (not available for steel frame size L1).

FP: Plenum for filter extraction on D version

H: Humidifier.

HG: Hot gas by-pass.

IE: Wooden cage packaging.

IG: Watch card.

IH: Serial interface RS485.

IM: Seawood packaging.

IP: Magnetohermic switch for auxiliary circuits.
IT: Magnetohermic switch for auxiliary circuits with RE and H.
K: Unit charged with ecological gas R407C.
Ka: Unit charged with ecological gas R134A.
Kc: Unit charged with ecological gas R410A.
KC: Spare F4 efficiency filters kit.
MF: Phase monitor
MP: Oversized microprocessor
PB: Condensing water pump (not available for steel frame size L1).
PL: Distribution plenum provided with adjustable grid for U, V, B versions.
PQ: Remote microprocessor.
PR: Fresh air inlet with filter.
RE: Electrical heater with aluminium armoured elements and safety thermostat.
RV: Personalized RAL paint.
SL: Main switch with padlock.
ST: Calibration damper.
SV: Gravity damper for U/V/B versions.
TE: Electronic thermostatic valve.
VP: Pressostatic valve for ED.W.
1M,2M,3M,4M,5M: different levels of higher available pressure for fans.


BW: Operaton for external low temperatures (up to -40°C).
C2: two-circuit coils
CV: Wired fans
FV: Supports for vertical air flow version
IM: Seawood packaging
RG: Fan speed controller
RM: Coil with fins in marine alloy
RR: Coil with copper fins

4 - INSTALLATION

4.1 Identification tag


The data for the identification of the unit are marked on a permanent tag (Picture 4) attached both on the packing and inside the unit, close to the electrical panel.



 The correct unit identification by means of the serial number is essential for the execution of any operation to carry out on the unit. The serial number must be always advised whenever submitting a request of technical service support.

4.2 Reception and inspection

It is very important to check the packing integrity immediately upon delivery. In case the packing is found damaged, it is necessary to accept the goods "with reservation" and indicate on the consignment note the state of the received goods and let the driver countersign it. Any claim concerning the delivered material must be sent to the manufacturer by fax or by registered letter within 8 days from the receiving date. It is advisable to unpack the unit only when the installation begins and possibly after the unit has been moved to the location where it must be installed.

 It is forbidden to stack units, even if they are packed. If the unit is stored after receiving, it must be not exposed to weaher agents, even if packed.

4.3 Handling

The handling of the unit must be carried out by expert personnel, equipped with appropriate equipment in relation to the weight and to the dimensions of the machine. During the handling operation, the machine must be always kept upright.




The weight of some models is unbalanced: check the unit stability before starting to handle it.

For any unit handling, please follow the instructions shown in (Picture 5). In case the fork lift is employed, the forks must be spaced out to the maximum allowed by the pallet size. In case the machine is moved by means of a crane, it is important to avoid that cables and belts exert a too high tractive effort on the packing that might damage it.



Angle α must not be greater than 30 °.



Picture 5

Table 3 shows the overall dimensions of the different models packaging included.

The overall dimensions of the units packaging included are indicated in the table here below.

TABLE 3

Model	Steel frame size	H	L	A	A1
61-81-91	L1	1955	540	610	760
101-121-141	L2		690		
151-171-201-172-192	L3		990		
221-241-251-291-301-341-201-232-272-342	M1	2155	1290	850	1000
321-361-451-302-362-442	M2		1600		
351-431-531-412-452-492	M3		1770		
471-521-601-482-532-572-602	M4		2030		
581-651-721-821-542-622-682-842	M5		2430		
762-892-1002-1102	M6		3000		

The lifting weight P of the unit is the result of the weight as indicated on the data sheet attached to the unit plus the packaging weight as shown in the following table.

TABLE 4

STEEL FRAME SIZE	L1	L2	L3	M1	M2	M3	M4	M5	M6
Packing weight (kg)	10	12	15	18	22	24	27	32	40

4.4 Arrangements and placing

The installation of the machine is under the responsibility of the installer who must supervise the execution operations. The execution of a correct installation presupposes that a plan has been drawn up by an expert and that is carried out by skilled and trained technicians.

In the following paragraphs there are some tips and information to keep in mind when planning and executing the machine installation.



The unit installation must comply with local existing laws.

Before placing the unit, the following points must be checked:

- Ø Connections for cooling, electrical, hydraulic and condensate drainage circuits must be done;
- Ø Enough room must be left around the unit to allow the routine maintenance, as shown in Picture 6 by the dashed area in front of the machine. It is necessary to keep some free room on the right and/or left side of the unit, in case option PR is installed or if connections are on the unit sides. If possible, also leave the necessary free lateral room for special maintenance, such as compressor, heat exchanger and fans replacement. These areas are shown in Picture 6 as a dashed area on the right and on the left of the unit, while their dimensions are indicated in Table 5;
- Ø The floor where the machine is positioned can bear the total weight of the unit under normal operation.




Table 5

	500 mm	1000 mm
X	- left hand connections - PR option on the left	- fans replacement M5- M6 U/V/B/D
Y	- right hand connections - PR option on the right - B version (air filters extraction)	- compressors replacement M1 - M4D, M5-M6 U/V/B/D - fans replacement L1-M4 U/V/B/D

Before starting to handle the unit to position it, it is necessary to identify the best way to arrive to the place, taking into consideration the unit overall dimensions and weight, the available lifting equipment and any optional accessory dimensions.

All units described in this manual do not need any special foundation, since they can be simply laid down on the chosen surface or arranged on a base frame (option) just placing a rubber gasket of about 5 mm thickness underneath.

Make sure that the aeraulic features of the unit, as described in the attached data sheets, match those required for the undertaken project.

In case of units provided with downflow air discharge, it is necessary to take into account the height of the floating floor because it can greatly influence the unit performance.

In order to avoid high noise level and / or unacceptable reductions of airflow, the height of the floating floor should be never inferior than the unit width.

Make sure that the value of the pressure drop of the air distribution system is not higher than the unit available pressure in its standard configuration. In case of special requirement, higher levels of available pressure are available as an optional.

Make sure that the number and the characteristics of the air suction and distribution grids are suitable for the unit airflow capacity.

For the installation of any spare accessory, strictly follow the instructions attached to each of them.

4.5 Cooling connections (ED. A, ED. M)

These units are supplied with nitrogen charge (20 bar). Discharge pressure carefully only before carrying out the cooling connections.

Since the machines are conceived to work with air cooling system, copper pipes must be employed for the connections to their ventilated condenser units which are installed outdoor.

The piping scheme is shown in Picture 7 (ED.A) and Picture 8 (ED.M).




Even if refrigerant is not classified as a toxic substance, pay the maximum attention during the refrigerant charge operation and strictly follow the security requirements in compliance with law by decree 81/08 ; in particular, the appropriate and necessary equipment must be worn to avoid contact, inhalation and ingestion.


If any of the above mentioned cases occurs, it is advisable to consult the security specifications for the operations of first aid and emergencies concerning the employed refrigerant.

In case it is necessary to go to the doctor, it is advisable to bring these refrigerant security specifications with you.


Picture 7: Piping diagram ED.A



Picture 8: Piping diagram ED.M



The horizontal section of the suction line must be realised with a slope not lower than 2% (2 cm / m) in the gas flow direction.



The pipe installation must be performed by a skilled refrigeration technician.

The piping path must be as shortest as possible in order to reduce the quantity of refrigerant gas and oil circulating and to reduce the pressure drop. If copper pipes have to cross electric wires, it is advisable to isolate the tubes in order to avoid the danger of inducted current. Lines must be realised with copper tubes, specifically conceived for cooling systems and they must have an appropriate diameter, as shown in Table 6 (ED.A) and Table 7 (ED.M) .

It is here reminded that the total piping length is the result of its geometrical calculation plus the length of valves, bents and fittings present on the line itself. If failing to have more accurate information, you can obtain the total length by multiplying the geometrical length of the line by 1,5 or 2.

Copper pipes must be adequately supported by brackets so as to make them secure and fasten, and at the same time allow thermal expansion of the copper tubes.

If the discharge pipes go through rooms where people normally live, it is advisable to install rubber vibration dampers and a sound attenuator as nearest as possible to the compressor.

The piping insulation, except for special requirements, can be applied on the following parts only:

- Ø Suction pipes (ED.M);
- Ø Discharge pipes (ED.A), where pipes are lapped by the unit air discharge (in the suspended floor); where pipes can be accessible to unauthorized people so that any damage or skin burn can be avoided.

During the piping installation, the refrigerant tubes must be sealed to prevent humidity and dirt go inside. The piping arrangement must consider easy access for operations like bracket insertion, tube welding and inspection.

Once pipes are placed, before carrying out the connections to the unit, the system must be leak tested by means of pressurized nitrogen. It is recommended to mark the pressure test value on a pressure gauge.



Do not exceed 20 bar when pressing with nitrogen.

The nitrogen also enables the circuit to dry up. If the circuit pressure drops, this means that the circuit is not sealed off. It is, then, necessary to let in a small quantity of refrigerant so that it is possible to locate any leak by means of appropriate detectors. If a leak is detected, after the repair, a new leak test must be carried out again.

Finally, the vacuum and the charge of the system can be executed following the instructions as described in par. 4.11

Picture 9




Table 6

ED. A		Leq						Picture 9					
		10 m		20 m		40 m		ØA	ØB				
		M	L	M	L	M	L						
61		12	10	16	10	16	10	10	12				
81	172	16				18	12			18	12		
91	192			18	22					22	16		
101	202					22	16					28	18
121	232												
141	272		28	16	35	22							
151	302	28					16	35	22				
171	342-362		28	16	35	22							
201		28					16	35	22				
221	412-442		28	16	35	22							
241	452-482	28					16	35	22				
251	492-532		28	16	35	22							
291	542-572	28					16	35	22				
301	602		28	16	35	22							
321	622	28					16	35	22				
341	682		28	16	35	22							
351		28					16	35	22				
361	762		28	16	35	22							
431	842	28					16	35	22				
451	892		28	16	35	22							
471	1002	28					16	35	22				
521	1102		28	16	35	22							
531		28					16	35	22				
581			28	16	35	22							
601		28					16	35	22				
651			28	16	35	22							
721		28					16	35	22				
821			22	22	42	22							

Table key:

- Leq: Length of the piping (m)
- L: Recommended diameter for the liquid piping (mm)
- M: Recommended diameter for the discharge piping (mm)
- ØA: Diameter for freon inlet connection
- ØB: Diameter for freon outlet connection

In case of longer lines than what stated in the above table, please contact the manufacturer.

Table 7

ED. M		Leq						Picture 9					
		10 m		20 m		40 m							
		S	L	S	L	S	L	ØA	ØB				
61		16	10	22	10	22	10	10	16				
81	172	22							12	28	12	16	18
91	192			28	16	35	18						22
101	202												
121	232			42	22	54	22						
141	272	42	22					54	22				
151	302			42	22	54	22						
171	342-362	42	22					54	22				
201				42	22	54	22						
221	412-442	42	22					54	22				
241	452-482			42	22	54	22						
251	492-532	42	22					54	22				
291	542-572			42	22	54	22						
301	602	42	22					54	22				
321	622			42	22	54	22						
341	682	42	22					54	22				
351				42	22	54	22						
361	762	42	22					54	22				
431	842			42	22	54	22						
451	892	42	22					54	22				
471	1002			42	22	54	22						
521	1102	42	22					54	22				
531				42	22	54	22						
581		42	22					54	22				
601				42	22	54	22						
651		42	22					54	22				
721				42	22	54	22						
821		22	22					54	22	22	42		

Table key:

- Leq: Length of the piping (m)
- S: Recommended diameter for the suction piping (mm)
- L: Recommended diameter for the liquid piping (mm)
- ØA: Diameter for freon inlet connection
- ØB: Diameter for freon outlet connection

In case of lines longer than what stated in the above table, please contact the manufacturer.

4.6 Condenser hydraulic connections (ED.W)

The units are designed to work with tower water. It is necessary that the refill water for the evaporator tower is adequately treated in order to avoid corrosion problems, limestone deposit and algae or any other microorganism proliferation.

It is also possible to use water from water city systems or from a well. In these cases, the water condenser can be equipped with a pressostatic valve as optional: when calculating the circulation pump size, the pressure drop of this component must be also kept into account.

On demand, the condensers can be sized to be able to employ a water and ethylene glycol mixture in a closed circuit cooled by a forced ventilation coil exchanger (dry-cooler) which dispels the heat into the atmosphere. The use of glycoled water allows the cooling circuit to also work at low outdoor temperatures. The percentage of ethylene glycol to be used is indicated in Table 8.

TABLE 8

Ethylene glycol percentage	5%	10%	15%	20%	25%	30%	35%	40%
Freezing temperature	-2.1	-4.5	-7.0	-9.0	-12	-16	-20	-25

When employing this mixture, the condenser must be equipped with a temperature control device of the anti-freeze mixture. If the anti-freeze mixture contains a lower ethylene glycol percentage than above recommended, there could be risks of freezing, while a higher percentage can reduce the unit performance. At the beginning of every winter, it is recommended to check the correct concentration of glycol in the system; please only use inhibited ethylene glycol in order to avoid rusting of the hydraulic circuit.

Do not use anti-freeze liquids unsuited to copper, stainless steel and to all other materials present in the system.

It is recommended to install a filter with grid not larger than 1 mm on the condenser water inlet.

It is also advisable to install a ball check valve on the condenser inlet and outlet so that it is possible to shut off the conditioning unit in case of special maintenance operations: the installation of a three-piece joint between the valves and the conditioning unit will ease these operations. The water system pressure must range between 1,5 and 3,5 bar.

4.7 Condensate drainage connection

The air conditioning unit is provided with a stainless steel tank collecting the condensate generated during the dehumidification phase. The tank must be connected to the drainage collector by means of a flexible pipe having internal diameter of 27 mm. The pipe shall be placed with a slope not lower than 1,5% (1,5 cm/m) toward the outlet direction.



To guarantee a correct condensate drainage, it is necessary to set up a siphon of at least 20 mm in the flexible pipe before doing the connection to the drainage collector.

4.8 Humidifier connections

On request, the unit can be supplied with an optional steam humidifier with immersed electrodes (Picture 10) having an appropriate capacity. It must be connected to a supply water line and to a drain water line according to the criteria described here below.

The humidifier is provided with a \varnothing 3/4" Gas male coupling for the supply water. The supply water line must have the following features:

- Ø Water flow not lower than 0,6 l/min;
- Ø Internal diameter not smaller than 6 mm;
- Ø Shutoff valve and mechanical filter with grid not larger than 100 μ m.

The humidifier must be supplied possibly with water from water mains having the following characteristics:

- Ø Flow pressure between 1 and 8 bar;
- Ø Temperature between 1 and 40°C
- Ø Hardness between 14 and 35 °Fr;
- Ø Specific conductivity (at 20°C) between 300 and 1250 μ S/cm.

On demand, it is available a unit which can work with a specific conductivity between 125 a 500 $\mu\text{S}/\text{cm}$.

For further details on chemical characteristics of the power supply with reference to the specific conductivity, please read the Humidifier Operating and Maintenance Manual.



The supply water must not be treated with softeners because they can cause electrodes corrosion and they can generate foam, thus compromising the correct operation of the unit.



It is not advisable to employ well water, process water coming from the cooling circuits or, in general, that may contain polluted chemicals or bacteria that could be spread in the environment together with the produced steam.



It is also inappropriate to use supply water containing disinfectants or anticorrosion compounds because they are potentially irritant.

The humidifier is provided with a coupling of 32 mm external diameter for water drainage, condensate and possible overflows. This coupling must be connected to a discharge line by means of a flexible pipe (supplied together with the unit) having internal diameter of 27 mm. It is necessary to realise a siphon in the flexible pipe immediately after the connection to the humidifier.

The discharge line must have the following characteristics:

- Ø Instantaneous water flow not lower than 4 l/min;
- Ø Internal diameter not smaller than 25 mm;
- Ø The piping material must be able to bear a temperature of at least 100°C;
- Ø It must be free from obstruction and without counter pressure;
- Ø It must have a slope not lower than 1,5% (1,5 cm/m) toward the outlet direction.

The drain water contains the same substances as the supply water, but in higher concentration, because of the steam production. This water can be therefore discharged to a collecting clear wastewater system.



Once the installation is completed, wash the supply water piping making the water running for few minutes directly in the drainage line (without entering into the humidifier); this will help to eliminate any waste or installation remains which could cause a unit malfunction.



Picture 10

4.9 Fresh air intake connection

The fresh air intake optional is installed inside the conditioning unit on the left side or, on demand, on the right side. The new air intake duct is connected to the nearest external intake through a coupling of 100 mm diameter, mounted on the left side panel of the unit. (Picture 11.a)

The fresh air intake optional is equipped with a filter easily removable for cleaning purpose on steel frame sizes from M1 to M6 (Picture 11.b); while on steel frame sizes from L1 to L3 the filter of the new air intake is made up of a layer of washable synthetic material.



Picture 11.a



Picture 11.b

4.10 Electric connections

Before carrying out the connection of the unit to the power supply, it is necessary to carefully check the following:

- Ø the power tension and frequency are the same data as stated on the unit identification tag (Picture 4);
- Ø make sure there is no humidity trace inside the electrical panel and on all electric and electronic components. In case humidity is found, detect and eliminate the cause of the infiltration;
- Ø make sure the circuit and the electric components have not been damaged during transportation, handling and positioning. If any damage is detected, proceed with the needed repair.
- Ø The electrical wires must be properly tightened; if necessary, tighten adequately any loose wire.



Only authorized and trained personnel can carry out any intervention on the electrical wiring.



Check the wiring diagram placed inside the key board.



Strictly comply with existing local regulations when performing the electrical connections.

4.10.1 Power supply connection (Picture 12)

The unit standard power supply tension is 400 V/3f/50Hz; on request, it is also possible to supply units with arrangements for special power supply tension (check the identification tag and the wiring diagram).

The unit is normally powered with a 5-pole cable (3 phases + neutral + earth).

Connect the phases and the neutral to the terminals of the main switch (L1, L2, L3 and, respectively, N) and the earth wire to its corresponding terminal (PE). Use a power supply cable of adequate cross section and of moderate length to avoid voltage drops.



Protect the power supply cable by means of an automatic differential switch of appropriate size and features. The cross section of the power supply cable and the size of the automatic switch can be found on Table 9, where it is indicated the main switch size according to different unit models and configurations.


4.10.2 User's terminal board connection

A user terminal board (Picture 13) is available with free contacts designed for:

- Ø generic alarm state (1);
- Ø unit remote ON/OFF (2).



For the exact correspondence of the terminal numbers, check the wiring diagram.



Picture 12

Picture 13



Table 9

Model	STD	H	RE
61-81-91	16A 4P	25A 4P	25A 4P
101-121-141	25A 4P	32A 4P	32A 4P
151-171-201	32A 4P	40A 4P	50A 4P
221-241-251-291	40A 4P	50A 4P	63A 4P
301-341	50A 4P	63A 4P	
321-361			
431-351			
451			80A 4P
531	63A 4P	80A 4P	100A 4P
471-521-601			
581			
651-721-821	80A 4P	100A 4P	
172-192	32A 4P	40A 4P	50A 4P
202			
232-272-342	40A 4P	50A 4P	63A 4P
302-362			
442	50A 4P	63A 4P	80A 4P
412-452-492	50A 4P		100A 4P
482-532	63A 4P		
572		80A 4P	
602	80A 4P	100A 4P	125A 4P
542-622-682			
842			
762	100A 4P		160A 4P
892-1002-1102		125A 4P	

Key:

STD: standard unit (without humidifier and electrical heater)

H: unit with humidifier (without electrical heater)

RE: unit with electrical heater or with both electrical heater and humidifier



The values shown in the above table refer to units with standard power supply 400V/3f/50Hz.

4.10.3 Warning in case of connection to the terminal board when optional "TE" is installed

In case the unit is provided with optional TE (electronic thermostatic valve), pay the maximum attention to the spare battery power supply.

"GB1" (spare battery) is an electronic device which guarantees a temporary power supply to the "Driver" device in case of sudden power supply shortage, thus allowing the immediate shutoff of the thermostatic valve.

Before performing any operation, it is advisable to check the charge of the battery as per the instructions;

- Ø power the control
- Ø press the button I/O
- Ø check parameter N4

For further information, check the control manual on chapter 7, section "input-output/driver" and chapter 9. If battery is flat, 48 hours are needed to charge it.

During the check-up operation before the unit startup, it is advisable to disconnect the spare battery to avoid that continuous power and disconnection operations might damage it.

- open the duct above the component GB1 (driver battery EVV) and disconnect the power supply cables (see the picture)



Once the check-up test is completed, it is reminded to re-connect the battery to bring the air conditioning unit in a safety status.



4.10.4 Condenser (ED. A) or motocondenser (ED.M) connections

The condensers and the remote condensing units must be connected to the appropriate wire terminals in the indoor unit by means of an electric cable having an adequate diameter and suitable features related to the capacity and the environment.

4.11 Vacuum and charge execution of the system (ED.A, ED.M)

4.11.1 General warnings

For a correct and reliable operation of the system, once the connection lines between the indoor and the outdoor units are carried out, it is extremely important to clear the circuit of any air, humidity, non-condensable gas and, in general, of any polluting substance presence before executing the refrigerant charge. The presence of solid particles like metal dust, welding debris and dirt of small dimensions that cannot be detected by the mechanical filters can cause serious damages to the surfaces in movement and involve a reduction in efficiency and of compressor life.



Do not perform any holes in the cooling circuit, the complete rescue of metal particles produced would be then prevented.

If excessive humidity persists inside the cooling circuit, negative consequences can arise. Humidity can freeze inside the thermostatic valve and can even clog it up, causing the unit stop because of the low-pressure alarm. A significant amount of humidity can saturate the filter drier in a very short time and it will be necessary to replace it (with consequent operating interruption of the system). Humidity chemically interacts with the refrigerants and especially with polyester lubricant oils (normally employed with refrigerant type R407C, R134a, R404A, etc.). This interaction creates acid substances that, if present in fair amount, can damage the compressor electric motor insulation provoking motor burns and rusted copper pipes that can generate solid impurity.



Reduce as least as possible the exposure of the circuit and its part to the atmosphere, especially if compressors are charged with polyester oil.

If non-condensable gases are not eliminated accurately from the circuit, they can gather inside the condenser and the liquid receiver. If gases are in the condenser, they can cause a reduction of the useful thermal exchange surface, meaning a condensing temperature increase and, consequently, a reduction of the energy efficiency and of the system reliability. In worst cases, the unit can be stopped by the activation of the high-pressure switch. Big amounts of non-condensable gases gathered in the liquid receiver can cause the malfunctioning of the thermostatic valve, in case a mixture of refrigerant and non-condensable vapor replaces liquid refrigerant. If this happen, there will be a strong reduction of the evaporating temperature up to the activation of the low-pressure switch, in worst cases, thus involving a reduction of the unit cooling capacity and a reduction of the system efficiency and life.

Picture 14



Picture 15





4.11.2 Vacuum execution

Once the cooling lines are completed and checked that no leaks are present, the vacuum must be executed as described here below (see Par. 4.5).




The indoor unit is normally leak tested by the manufacturer by cooling circuit pressurization.

 The unit is supplied with nitrogen pressure (20 bar). Therefore, if during the installation it results that the cooling circuit is not pressurized, this means that there is a leak. It is necessary to detect it and repair it before going on with the installation operations.

 Before starting the circuit vacuum operation, make sure all nitrogen contained in the liquid receiver has been discharged.

a) Connect a vacuum pump (a two-stage pump able to keep a pressure of 0,04 mbar - Picture 14) to the system employing the charge connections present on suction (Picture 15) and on liquid lines. The vacuum pump must have a suitable water flow capacity for the circuit size.

 Do not use the compressor for carrying out the vacuum inside the cooling circuit.

 Make sure all valves are open in order to avoid that some circuit parts result cut off.


b) Let the vacuum pump work until the pressure shown on the appropriate vacuum meter (Picture 14) does not go below 10 mbar.

c) Isolate the pump from the circuit by means of the appropriate cut-off valves and wait for 30 min.

d) If pressure goes on increasing during the pump stop period or if it is impossible to reach the desired pressure value, it means there is a leak in the circuit. It is necessary to detect and repair the leak, and after that, a new procedure must be performed again starting from step b).


e) If pressure goes up until it reaches a climax value, it means the circuit contains a big amount of humidity. In this case, it is necessary to let in nitrogen in the circuit (up to about 2 bar) and then repeat steps b), c) and e) for at least twice, then proceed with step f).


f) If pressure stabilizes after a short increase, it means the circuit is leak proof and reasonably dried. Start up again the pump after the shut-off valves are open and let it operate for 2-4 hours according to the circuit size after pressure has returned below 10 mbar.

 Do not operate the compressor nor empty a megahom meter while the circuit is vacuum.


4.11.3 Refrigerant charge execution

Once vacuum is completed, the circuit must be charged with the exact quantity of refrigerant and, if necessary, of anti-freeze oil.


 Avoid any refrigerant gas release in the environment during the charge operations.

 ED.W units are supplied with refrigerant and anti-freeze oil charge included, therefore they must not undergo the following operations, unless some maintenance operations on the cooling circuit are needed.

a) Connect a full up refrigerant gas cylinder to the circuit employing the charge connections present on the liquid line.

 Make sure the refrigerant you are going to use for the circuit charge is the same as shown in the unit identification tag. In case of discrepancies, contact the manufacturer.

b) Open the cylinder valve and charge the refrigerant until the circuit pressure reaches the same pressure as in the cylinder (if needed, repeat the operation with additional gas cylinders).

 If the refrigerant is a mixture compounds, make sure to let enter the circuit in a liquid state in order to avoid compounds separation. On this purpose, cylinders are provided with two distinct valves: one for the vapor and one for the liquid.

c) Shut off the cylinder valve, disconnect it from the liquid line and connect it to the suction line (possibly prior to the evaporator).

d) Start up the unit, open the cylinder liquid valve and complete the charge (if needed, use more cylinders) until the sight glass located immediately after the filter drier becomes clear and does not present foam or gas bubbles during the operation in nominal conditions.

In order to facilitate the charge operation, the following tables show, as an indication, the necessary amount of refrigerant to charge the different types of indoor units and the corresponding connecting pipes. For a correct calculation of the refrigerant quantity, it must be also taken into account the volume of the outdoor unit cooling circuit and of any other component installed (such as additional liquid receivers, oil separators, etc.). In case the cooling lines are very long or in case oil separators are installed on the compressors discharge, a fair quantity of anti-freeze oil must be added.

Check if the employed oil is compatible with the one charged in the compressor (check it out in the compressor's identification tag).

In case oil separators are employed, add the lubricant quantity suggested by the manufacturer.

If cooling lines are longer than 30 m, charge about 0,2 kg of oil every 10 m of piping (beyond 30 m). In any case, check the correct oil charge by checking the oil level through the compressor sight glass after about 30 minutes of standard operation mode.

An overload oil charge can lead to a system efficiency drop and to compressor breaking.

Table 10.a		Refrigerant charge (kg) (*)	
Steel frame size	Model	ED.A	ED.M
L1	61-81	2,4	1,1
	91	2,7	1,4
L2	101-121	3,0	1,7
	141	3,4	2,1
L3	151-171	4,1	2,7
	201	4,7	3,4
M1	221-241	5,2	3,8
	251-291	6,4	5,1
	301	7,6	5,1
	341	8,9	6,4
M2	321- 361	9,0	6,5
	451	11	8,1
M3	351-431	10	7,5
	531	12	9,3
M4	471-521	11	8,9
	601	14	11
M5	581-651	13	10
	821	15	13

Table 10.b		Refrigerant charge (kg) (*)	
Steel frame size	Model	ED.A	ED.M
L3	172	2,7	1,4
	192	3,0	1,7
M1	202-232-272	3,2	1,9
	342	4,5	3,2
M2	302-362	4,6	3,2
	442	5,4	4,1
M3	412-452	5,1	3,7
	492	6,0	4,7
	482-532	5,8	4,5
	572	7,0	4,5
M4	602	8,1	5,6
	542	6,5	5,1
M5	622-682	7,7	5,1
	842	9,0	6,4
M6	762-892	9,5	7,0
	1022-1102	11	8,7

Table 10.c		Refrigerant weight for every 10 m of piping										
D _e (mm)	6	10	12	16	18	22	28	35	42	54	64	76
M _{asp} (kg/10)	0,003	0,013	0,020	0,040	0,052	0,079	0,13	0,20	0,30	0,49	0,71	1,0
M _{man} (kg/10m)	0,011	0,042	0,07	0,13	0,16	0,25	0,42	0,6	1,0	1,6	2,3	3,3
M _{liq} (kg/10)	0,15	0,55	0,86	1,7	2,2	3,3	5,6	8,4	13	21	30	43

Table key

D_e = external pipe diameter

M_{asp} = refrigerant weight for the suction line

M_{man} = refrigerant weight for the discharge line

M_{liq} = refrigerant weight for the liquid line

5 - OPERATION

5.1 First startup


Before starting the unit, the following simple operations must be carried out.

5.1.1 Cooling circuit (ED.A, ED.M)

Once all operations are completed as described in par. 4.11 'Vacuum and charge execution of the system', the unit is ready for the startup. Make sure the valves are open according to the following instructions:

- Ø Unscrew the stylus protective cap (Picture 16);
- Ø Rotate the stylus anti-clockwise until the end (Picture 17);
- Ø Rotate the stylus clockwise for one turn (if the manometer plug 1 is employed);
- Ø Screw well the cap tightening it, so to avoid any gas leakage.

Picture 16



Picture 17





5.1.2 Hydraulic circuit (ED.W)

Make sure that the hydraulic circuit is completely air free and that the water flow and the condensing temperature correspond to the right ones.

5.1.3 Startup

Perform all operations as described in par. 4.10 'Electric connections' and then follow the instructions here below: Turn the main switch to ON position; make sure the unit is OFF from the keyboard.

 Wait at least for 3 hours before starting the unit to allow the oil sump heater to pre-heat the oil. Start the unit pressing the ON/OFF button on the microprocessor keyboard.

 In case of 3-phase motors, check the fans and the compressors rotation direction; if rotation is reversed, two out of the three phases must be inverted in the terminals of the main switch.

Once the unit is started, after a short period needed to the microprocessor for an auto-test, the unit electric fans will start to rotate. At this point, all system components will start working automatically according to the selected and detected thermal and humidity parameters.

To stop the air conditioning unit, push the ON/OFF button on the microprocessor keyboard.

 If the unit should not work for more than 24 hours, turn the main switch to OFF position.

5.1.4 Setup

The setup must be performed when the unit is operating in conditions as close as possible to the nominal ones.

Make sure:

- Ø The thermal load is adequate;
- Ø Doors and windows are shut;
- Ø Surrounding spaces are clean.

Check the suction gas heating and, if needed, adjust the thermostatic valve setting as described here below. When the unit is working in nominal conditions, connect a manometer on the low pressure side. Check the gas temperature on the compressor intake (Picture 19) by means of a thermometer (Picture 18). The overheating intake value is the difference between the detected temperature and the saturation temperature (dew value for mixture) corresponding to the pressure shown on the manometer. If overheating is over 10°C, the thermostatic valve must be opened, while if it is below 5 °C, the valve must be shut off (Picture 21 cap removal and Picture 22 opening adjustment).

Valve adjusting operations must be always carried out with caution, turning the adjusting screw only half turn each time; wait for few minutes before every new adjustment in order to allow the unit to reach steady conditions.



Picture 18




Picture 19 example
Gas: R407 C
Intake temp.: 15°C
Intake pressure: 5,5 bar
at 10°C
Overheating:
15 - 10 = 5°C

Picture 20



Picture 21



The thermostatic valve adjustment is a very delicate operation, therefore it must be carried out by a skilled technician.

5.1.5 Microprocessor setting

Make sure the desired thermal and humidity parameters are set on the microprocessor.

If the preset parameters need to be changed, proceed as described in the microprocessor manual (see attachment).



Standard units are designed to work with room temperature between 22 and 27 °C (50% relative humidity); working at lower temperatures can generate frost on the evaporator.

5.1.6. Steam production setting (unit with humidifier)

Steam production must not exceed 60 - 70% of humidifier maximum capacity in order to guarantee a long operating life of the unit.

To set and modify the operating parameters, check the humidifier manual (here attached).

Table 11: Safety devices setup

Device	Bar Intervention	Bar Reset
High pressure switch	27,5	22
High pressure safety valve	29	
Low pressure switch	2,3	3,5

Table 12: Main electric components (see attached wiring diagram)

MODEL	AUXILIARIES		COMPRESSORS		FANS	REMOTE CONDENSERS		OPTIONAL AA	OPTIONAL H		OPTIONAL RE	
	FUT 10x38	FUA 10x38	QFC1 (curva "D")	KMC1	KMV1	QFCR1	KMCR1	FUAA	FUU 10x38	KMU	FR 10x38	KMR
61	2A 2P	2A 1P	4A 3P	9A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
81-91	4A 2P	2A 1P	6A 3P	9A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
101	4A 2P	2A 1P	10A 3P	9A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
121-141	4A 2P	2A 1P	10A 3P	9A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
151-171	4A 2P	2A 1P	10A 3P	12A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
201	4A 2P	2A 1P	16A 3P	12A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
221-241	4A 2P	4A 1P	16A 3P	18A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
251	4A 2P	4A 1P	20A 3P	18A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
291	4A 2P	4A 1P	20A 3P	18A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
301-341	4A 2P	4A 1P	25A 3P	25A	12A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
321-361	4A 2P	4A 1P	25A 3P	25A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
451	4A 2P	4A 1P	32A 3P	32A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
351	4A 2P	4A 1P	25A 3P	32A	18A	6A 2P	9A	500mA vetro	20A	12A	16A	12A
431	4A 2P	4A 1P	32A 3P	32A	18A	6A 2P	9A	500mA vetro	20A	12A	16A	12A
531	4A 2P	4A 1P	32A 3P	32A	18A	10A 3P	9A	500mA vetro	20A	12A	16A	12A
471	4A 2P	4A 1P	32A 3P	32A	18A	10A 3P	9A	500mA vetro	20A	12A	16A	12A
521	4A 2P	4A 1P	32A 3P	32A	18A	10A 3P	9A	500mA vetro	20A	12A	16A	12A
601	4A 2P	4A 1P	40A 3P	32A	18A	10A 3P	9A	500mA vetro	20A	12A	16A	12A
581	4A 2P	4A 1P	40A 3P	32A	25A	10A 3P	9A	500mA vetro	20A	12A	20A	25A
651	4A 2P	4A 1P	40A 3P	40A	25A	10A 3P	9A	500mA vetro	20A	12A	20A	25A
721-821	4A 2P	4A 1P	50A 3P	50A	18A	10A 3P	9A	500mA vetro	20A	12A	20A	25A

MODELLO	AUXILIARIES		COMPRESSORS		FANS	REMOTE CONDENSERS		OPTIONAL AA	OPTIONAL H		OPTIONAL RE	
	FUT 10x38	FUA 10x38	QFC1-2 (curva "D")	KMC1-2	KMV	QFCR1-2	KMCR1-2	FUAA	FUU 10x38	KMU	FR 10x38	KMR
172-192	6A 2P	4A 1P	6A 3P	9A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
202	6A 2P	4A 1P	6A 3P	9A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
232-272	6A 2P	4A 1P	10A 3P	9A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
342	6A 2P	4A 1P	10A 3P	12A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
302-362	6A 2P	4A 1P	10A 3P	9A-12A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
442	6A 2P	4A 1P	16A 3P	18A	9A	6A 2P	9A	500mA vetro	10A	9A	10A	9A
412	6A 2P	4A 1P	16A 3P	12A	18A	6A 2P	9A	500mA vetro	20A	12A	16A	12A
452-492	6A 2P	4A 1P	16A 3P	18A	18A	6A 2P	9A	500mA vetro	20A	12A	16A	12A
482-532	6A 2P	4A 1P	16A 3P	18A	18A	10A 3P	9A	500mA vetro	20A	12A	16A	12A
572	6A 2P	4A 1P	20A 3P	25A	18A	10A 3P	9A	500mA vetro	20A	12A	16A	12A
602	6A 2P	4A 1P	25A 3P	25A	18A	10A 3P	9A	500mA vetro	20A	12A	16A	12A
542	6A 2P	4A 1P	20A 3P	18A	25A	10A 3P	9A	500mA vetro	20A	12A	20A	25A
622	6A 2P	4A 1P	25A 3P	25A	25A	10A 3P	9A	500mA vetro	20A	12A	20A	25A
682	6A 2P	4A 1P	25A 3P	25A	18A	10A 3P	9A	500mA vetro	20A	12A	20A	25A
842	6A 2P	4A 1P	32A 3P	32A	18A	10A 3P	9A	500mA vetro	20A	12A	20A	25A
762	6A 2P	4A 1P	25A 3P	25A	32A	10A 3P	9A	500mA vetro	20A	12A	20A	25A
892-1002	6A 2P	4A 1P	32A 3P	32A	32A	10A 3P	9A	500mA vetro	20A	12A	20A	25A
1102	6A 2P	4A 1P	32A 3P	32A	25A	10A 3P	9A	500mA vetro	20A	12A	20A	25A

5.2 Fault alarm and display system

The troubleshooting is realised by the microprocessor, which activates an alarm and shows on its display the type of fault occurred (see also the attached microprocessor manual).

Since the alarm state is very often generated by an unfitted electric contact, in case of fault make sure all wiring connections are plugged in the corresponding terminals.

In case of fault, consult the attached microprocessor manual to check the parameters setting has been done properly.

5.3 Troubleshooting

TROUBLE	POSSIBLE CAUSE	CHECK / CORRECTIVE ACTION
1) The unit does not work	A) The electric panel is not powered	Check presence of electric tension; make sure the main switch is closed.
	B) The auxiliary circuit is not powered	Check fuses FUT and FUA
2) The unit does not start	A) The microprocessor does not start the unit	Check the electric connections to the microprocessor
	B) The external impulse to the microprocessor fails	Check the remote ON/OFF contact is closed
3) Room temperature too high (high temperature alarm signal)	A) The unit does not work	See troubles 1 and 2
	B) The control system setting is not correct	Check the setting of the control system
	C) The air flow capacity is too low	See trouble 6
	D) The compressor does not work	See trouble 13
	E) The compressor output is not sufficient	1) See trouble 9 2) See trouble 12
	F) The control system does not work	Consult the attached Microprocessor manual
	G) Thermal load higher than estimated	Check the room thermal load value
4) Room temperature too low (low temperature alarm signal)	A) The control system setting is not correct	Check the setting of the control system
	B) The electric heaters do not work (if installed)	See trouble 15
	C) The control system does not work	Consult the attached Microprocessor manual
	D) Thermal loss higher than estimated	Check the thermal loss value
5) Room humidity too high (if the humidity control is installed) (high room humidity alarm)	A) The control system setting is not correct	Check the setting of the control system
	B) Latent load higher than estimated	Check the room latent load value
	C) The compressor does not work when in dehumidification phase	See trouble 13
	D) The control system does not work	See the attached Microprocessor manual
6) Low or no air flow (flow or fans alarm)	A) Fans are not powered	Check the fans electric circuit
	B) Clogged filter (filter alarm, if installed)	Clean or replace the filter
	C) Obstruction in the air duct or excess of pressure drop in the air ducts	Check the total pressure drop and compare it with the unit available pressure
	D) Fan heat protection system is activated	Check fan winding resistance; after reset, check tension and electric absorption
7) High pressure switch is activated	A) The control system of the condensation pressure is not working properly (if installed)	Make sure the control system of condensation is set and it works
	B) One or more condensing fans are out of order (ED.A, ED.M units)	Check that the internal heat protection of the out of order fans does work: replace the defective fans
	C) The high pressure switch is not properly set	Replace the high pressure switch
	D) Output pressure too high	See trouble 9
	E) The condensation water capacity is not sufficient (ED.W unit)	1) Check all valves are positioned correctly; 2) Make sure there is no air in the circuit
8) Low pressure switch is activated	A) Low pressure switch is not set	Replace the low pressure switch
	B) Suction pressure too low	See trouble 12

TROUBLE	POSSIBLE CAUSE	CHECK / CORRECTIVE ACTION
9) Compressor high pressure output	A) Air to the condenser too hot	Check the presence of any condensation air re-cycle
	B) Insufficient condensation air flow	Make sure there is no obstruction to the air flow in the finned exchanger coil (see par. Arrangements and placing)
	C) Suction pressure too high	See trouble 11
	D) Clogged fins of the condenser coil	Clean the exchanger coil removing the clogging material (leaves, paper, seeds, etc.)
	E) Circuit charged with too much refrigerant: condenser partially flooded	Under-cooling of the refrigerant too high: remove some refrigerant from the circuit
	F) Non condensable air or gas in the circuit	The flow sight glass presents gas bubbles. The compressor discharge temperature is high; the cooling circuit must be discharged and recharged after the vacuum execution
	G) Too hot water to the plate condenser	Check the capacity of the condensation water cooling system
	H) Insufficient condensation water flow capacity	Check the system pressure drop and compare it with the pump available pressure
	I) Plate condenser encrusted	Wash the exchanger with specific products
10) Compressor low pressure output	A) The control system of the condensation pressure is not working properly	Check setting and working of the condensation control system
	B) Suction pressure too low	See trouble 12
11) Compressor suction high pressure	A) Thermal load higher than estimated	Check the room thermal load value
	B) Discharge pressure too high	See trouble 9
	C) Liquid refrigerant return to the compressor intake	Make sure the overheating of the thermostatic valve is correct; check the valve bulb is well placed, fixed and insulated.
12) Compressor suction low pressure (possible frost on the coil battery)	A) Room temperature too low	See trouble 4
	B) The air flow capacity is too low or absent	See trouble 6
	C) Clogged refrigerant filter	Check the refrigerant filter
	D) Defective thermostatic valve or not properly set	Check the overheating of the thermostatic valve is correct: check the thermostatic element is not broken
	E) Insufficient refrigerant charge	Check possible leakage and recharge
	F) Discharge pressure too low	See trouble 10
13) The compressor does not work	A) Automatic switch activated	Reset the automatic switch; check the cause of the short circuit
	B) Compressor internal heat protection activated	Check the compressor winding resistance; after reset, check tension and electric absorption; check the working parameters are in the normal range of values
	C) Contactor does not work	Check the contacts and the contactor coil
14) The compressor is noisy	A) Liquid return to the compressor	Check working and overheating of the expansion valve
	B) The compressor is damaged	Replace the compressor
15) The electric heater does not work (if installed)	A) Safety thermostat activated	1) The air flow capacity is too low: see trouble 6 2) Check if safety thermostat works properly and replace it if needed
	B) Fuses activated	Replace the damaged fuses
	C) Contactor does not work	Check the contacts and the contactor coil
16) Probe alarm	The probe corresponding to the alarm code is defective or disconnected	Check the connection of the probe; in case of defect, replace it

5.4 Routine maintenance

	Monthly	Quarterly	Annual
Air filter cleaning	X		
Condensate tank cleaning		X	
Condenser coil cleaning (EDA/M)			X
Humidifier cleaning		X	
Check of cooling lines and their insulation		X	
Compressor noise level check	X		
Fans noise level check		X	
Electric connection tightening check		X	
Contactors status check		X	
Check of duct insulation status			X
Condenser water flow check (EDW)	X		
Sight glass check		X	
Electric absorption check		X	
Working pressures check		X	
Unit general conditions check			X
Probe setting check			X
Set parameters check		X	
Refrigerant filter pressure drop check			X
Safety valve check			X
Safety pressure valve check		X	
Electric protection check		X	

6 - DISMANTLING

When the unit has to be dismantled, drain the cooling circuit and collect the refrigerant gas by means of an adequate receiver, in order to protect people and environment.




Never release the gas contained in the cooling circuit in the environment.

When dismantling the unit or when replacing the compressor, carefully collect the oil compressor and deliver it to an authorized company for oil disposal.



Never release the oil compressor in the environment.

USE AND MAINTENANCE MANUAL



AIR CONDENSERS

With axial fans

CR/CRS/CRU

TABLE OF CONTENTS

1	WARNINGS	Pag. 44
2	TRASPORTATION.....	Pag. 45
3	CHECKS FOR A CORRECT INSTALLATION	Pag. 45
4	WARNING FOR A CORRECT PLACING.....	Pag. 46
4.1	Technical Specification	Pag. 46
4.2	Placing	Pag. 46
4.3	Electric connections	Pag. 46
5	INSTALLATION	Pag. 47
6	GENERAL MAINTENANCE.....	Pag. 48


1 - WARNINGS

Keep this technical manual all along the condenser's life.

Read carefully the manual before the installation and before any operation on the unit.

Use the condenser only for the use it has been designed for: the manufacturer disclaims all responsibility in case of misuse.

The interpreting key for the condenser initials is described here below:



2 - TRANSPORTATION

During the transportation, avoid to press the packing improperly and always keep it in the position indicated on it.

Unpack the unit as close as possible to the place where it has to be installed. Once unpacked, avoid to hit the components.


During the air conditioner installation and handling, wear the appropriate gauntlets in order to avoid to be hurt by the unit cutting parts (ex. Fins).

3 - CHECKS FOR A CORRECT INSTALLATION



In order to avoid any damage during the lifting operation, use a beam and connect it to all available hooks as shown in Picture 1.

- a) Make sure the floor and the structures can bear the unit weight;
- b) Do not install the unit in closed spaces;
- c) Leave an adequate free space to allow a correct air suction and discharge and an easy maintenance (see Par. 4.2);
- d) Make sure the condenser is properly fixed to the supporting floor;
- e) Check the electric power supply fits with the motor-fans characteristics;
- f) Condensers are equipped with axial motor-fans, therefore they are not appropriate for being ducted or for bearing higher available pressure;
- g) Make sure the operating conditions (temperature and pressure) are conform to the ones estimated in the plan;
- h) Make sure all electric connections are in compliance with existing local regulations;
- i) Only qualified personnel is allowed to have access to the unit for any required operation, in accordance with the laws in force;
- l) During the installation, suitable fixing and supporting systems for the unit must be foreseen.



Picture 1







Before any maintenance operation, make sure the electric power supply is disconnected from the main source: the electric parts might be connected to an automatic control.

4 - WARNINGS FOR A CORRECT PLACING

4.1 Technical specification

See the attached technical specification sheet.

4.2 Placing



4.3 Electric connections

See the attached wiring diagram.


The thermal contacts are activated following the temperature and they are installed in the motors windings: when the temperature exceeds the maximum allowed permanent value, an electric contact is opened.

Carefully follow the attached wiring diagram to avoid any damage to the motor. Before employing an rpm regulation system, check if it is compatible with the motor: non-compatible systems can cause noise and damages. Emicon A. C. S.p.a. disclaims all responsibility for the performance of units equipped with a regulation system.

5 - INSTALLATION

For a correct installation, follow the tips here below:

- 1) Size properly the pipes in order to avoid as much as possible a pressure drop and a reduction of refrigerant speed, since both factors are essential for the oil drag. If necessary, an oil separator must be installed (3).
- 2) In case the discharge line goes through rooms where people normally live, install both a vibration damper (1) and a silencer (2) as close as possible to the compressor, on the discharge line.
- 3) Do not convey the air flow directly on a surface having a reflecting power or able to increase the condenser noise level.
- 4) Do not reverse for any reason the refrigerant inlet and outlet collectors.
- 5) Place the condenser preferably in a position where the coil has a minimum direct exposure to sun radiations since they could change the condensation pressure.
- 6) In all installations, make sure the airflow does not collide with other currents of air going in the opposite direction.
- 7) Strictly follow the local regulations in force.



1. Anti-vibration damper
2. Discharge silencer
3. Oil separator
4. Low pressure gauge
5. High pressure gauge
6. A slope not lower than 1% must be foreseen between the outlet collector and the liquid receiver

The following table shows the necessary quantity of refrigerant for a correct charge of the different models of remote condensers.

CONDENSER MODEL			REFRIGERANT CHARGE
CR	CRS	CRU	
8	/	/	0,8 kg
11	7	/	1,5 kg
14	10	/	1,2 kg
18	13	/	1,8 kg
27	22	18	2,9 kg
30	25	20	3,8 kg
36	29	23	4,5 kg
45	/	28	6,0 kg
46	35	/	7,5 kg
49	42	32	5,7 kg
53	/	/	7,6 kg
59	57	43	9,0 kg
71	67	51	12 kg
90	85	68	14 kg
97	/	/	15 kg
/	99	74-87	18 kg
/	/	98	24 kg

6 - GENERAL MAINTENANCE

Check periodically the fasteners, the electric connections and the connections to the cooling system.

Clean periodically the unit to avoid any accumulation of harmful substances. It is advisable to use normal soapy water. Do not use solvents, aggressive, abrasive or ammoniac agents.



Only expert and qualified personnel can carry out the general maintenance.

USE AND MAINTENANCE MANUAL



STEAM HUMIDIFIER

1	INTRODUCTION	Pag. 52
1.1	Principle of operation	Pag. 52
1.2	Operation and unit components	Pag. 52
2	USE	Pag. 53
2.1	Main warnings	Pag. 53
2.2	Supply water characteristics... ..	Pag. 53
2.3	Startup, check and stop	Pag. 54
2.3.1	Preliminary checks... ..	Pag. 54
2.3.2	Startup with vacuum cylinder	Pag. 54
3	SETTING	Pag. 55
3.1	Electric components... ..	Pag. 55
3.2	Dip-switch	Pag. 55
3.3	Connectors	Pag. 55
3.4	Led	Pag. 55
3.5	Digital input terminals... ..	Pag. 55
3.6	Wiring diagram for single phase humidifier... ..	Pag. 56
3.7	Wiring diagram for three phase humidifier... ..	Pag. 56
3.8	Types of alarm	Pag. 57
3.9	Alarms description	Pag. 58
4	MAINTENANCE	Pag. 59
4.1	Steam cylinder replacement	Pag. 59
4.2	Periodical checks	Pag. 59
4.3	Unit cleaning	Pag. 60
5	TROUBLESHOOTING	Pag. 61
6	DISMANTLING	Pag. 61

1 - INTRODUCTION

The humidifier described in this manual is an immersed electrode steam humidifier and it is equipped with the most advanced microprocessor technology.

The operation is completely automatic and it can be employed in any geographical area since it is able to adapt its functioning according to the chemical - physical characteristics of water, provided that water is drinkable and it is not demineralised.

1.1 Principle of operation

By giving an electric tension to two metal electrodes immersed in water, an electric current is generated and it heats water up to make it boil. As a matter of fact, as long as water contains a minimum quantity of salts, it acts as an electric heater which closes the circuit between two electrodes.

1.2 Operation and unit components


When a steam production is needed, the electronic control sends an electric tension to the electrodes immersed in the water contained in the boiler, by closing the appropriate contactor. Steam production is controlled with an amperometric transformer (TAM) which measures the energy transferred from water.

When water level decreases and, consequently, energy goes below the set parameter, the fill electrovalve is open to allow water to reach the fill tank. From here, water flows inside the cylinder by gravity.

The two small electrodes located on the top of the cylinder monitor that the water level does not exceed the maximum value. As a matter of fact, beyond this level the water is drained by means of the overflow pipe into the fill tank.

The other two electrodes placed on the fill tank measure the supply water conductivity. This is useful for the electronic control in order to optimize the humidifier operation following the chemical characteristics of water.

The fill electrovalve is activated from the control as much frequently is needed depending on the supply water characteristics in order to maintain the optimal saline concentration inside the cylinder.



n.	description
1	Supporting frame
2	Cylinder
3	Draining electrovalve
4	Exhaust pipe fitting swinging at 90°
4a	Flat Pipe fitting (equipped)
5	Fill tank + Conductivity meter
6	Supply electrovalve

2 - USE

2.1 Main warnings



The electric components contained in the unit are powered.

Only qualified and trained personnel must carry out any operations on the unit.




The unit contains hot surfaces, in particular:



Ø The steam cylinder can reach temperatures over 60°C;

Ø The steam produced and therefore the draining pipe, in particular conditions, can reach the temperature of 100°C.

n.	description
1	Supply Electrovalve
2	Flow limiting device
3	Supply Pipe
4	Fill Pipe
5	Overflow pipe
6	Electrodes to measure conductivity
7	Supply tank - overflow
8	High level electrodes
9	Steam outlet
10	Electrodes (2/6 for monophase models, 3/6 for triphase models)
11	Cylinder case
12	filter
13	Draining Electrovalve
14	Exhaust corrugated pipe
15	Draining Column
16	Exhaust pump



2.2 Supply water characteristics

LIMIT VALUES OF SUPPLY WATERS WITH MEDIUM-HIGH CONDUCTIVITY
FOR HUMIDIFIERS WITH IMMERSSED ELECTRODES

Parameter	Unit	Limit
Hydrogenions Activity	pH	-
Specific conductivity at 20°C	°R 20 °C	-
Total dissolved solids	TDS	-
Fixed Residual at 180°C	R ₁₈₀	-
Total hardness	TH	-
Temporary hardness	-	-
Iron + Manganese	-	-
Chlorides	-	-
Silicon Dioxide	-	-
Residual Chloride	-	-
Anhydrite	-	-
Metallic matters	-	-
Solvents, diluents, soaps, lubricants	-	-

LIMITS	
Min.	Max
7	8,5
300	1250
(1)	(1)
(1)	(1)
100(2)	400
60(3)	300
0	0,2
0	30
0	20
0	0,2
0	100
0	0
0	0

(1) Values depending on the specific conductivity: generally speaking: TDS--= 0,93 ° 20; R₁₈₀--=0,65 ° 20

(2) Not less than 200% of chlorides content in mg/l of Cl

(3) Not less than 300% of chlorides content in mg/l of Cl

LIMIT VALUES OF SUPPLY WATERS WITH MEDIUM-LOW CONDUCTIVITY

FOR HUMIDIFIERS WITH IMMERSSED ELECTRODES

				LIMITS	
				Min.	Max
Hydrogenions Activity	pH	-		7	8,5
Specific conductivity at 20°C	°R 20 °C	-	µS/cm	125	500
Total dissolved solids	TDS	-	mg/l	(1)	(1)
Fixed Residual at 180°C	R ₁₈₀	-	mg/l	(1)	(1)
Total hardness	TH	-	mg/l CaCO ₃	50(2)	250
Temporary hardness		-	mg/l CaCO ₃	30(3)	150
Iron + Manganese		-	mg/l Fe+Mn	0	0,2
Chlorides		-	ppm Cl	0	20
Silicon Dioxide		-	mg/l SiO ₂	0	20
Residual Chloride		-	mg/l Cl	0	0,2
Anhydrite		-	mg/l CaSO ₄	0	60
Metallic matters		-	mg/l	0	0
Solvents, diluents,soaps, lubricants		-	mg/l	0	0

(1) Values depending on the specific conductivity; generally speaking: TDS≈= 0,93 * ° 20; R₁₈₀≈=0,65 * ° 20

(2) Not less than 200% of chlorides content in mg/l of Cl

(3) Not less than 300% of chlorides content in mg/l of Cl

Warning: there exists no reliable relation between hardness and conductivity of water.

Do not treat water with softeners! They can cause electrodes corrosion and generate foam, thus involving troubles of irregular functioning.



It is not advisable:



To employ well water, industrial water, process water coming from the cooling circuits or contaminated water with chemical or bacteriological substances;

Ø To employ supply water containing disinfectants or anticorrosion compounds because they are potentially irritant.

2.3 Startup, check and stop



Before the startup, make sure the humidifier is in perfect condition, there are no water leakages and the electric parts are dry.

Do not give power, if the unit is damaged or partially wet!



Once the installation is completed, purge the supply water pipe for about 30 minutes letting water flow directly to the drainage line without entering the humidifier; this will help eliminate any remains or installation debris which could clog the drainage valve and cause foam generation during boiling.



Before starting the unit, it is advisable to eliminate the PE film around the pipe to allow a correct heat exchange (the film is part of the pipe packing)

2.3.1 Preliminary checks

Before starting the humidifier, it is necessary to check the following:


- Ø Hydraulic and electric connections and the steam distribution system must be performed according to the instructions described in this handbook
- Ø The water shut-off valve on humidifier must be opened;
- Ø The line fuses must be installed and they must not be damaged;
- Ø Terminals AB of control CP4 must be jumpered or must be connected to the remote ON/OFF contact and the latter must be closed;
- Ø The steam outlet pipe must not present any choking.


2.3.2 Startup with vacuum cylinder


This phase is performed automatically as soon as the humidifier starts: before obtaining the nominal steam production, it is necessary to wait for an adequate period of time which mainly depends on the supply water conductivity and it may also take a few hours.

3 - SETTING

The control CP4 is a microprocessor electronic card which is installed on the unit electric board when Emiro microprocessor is used.

 CP4 card is not present in case Emiplus microprocessor is installed, since CP4 functions are already integrated in Emiplus software. In this case, for humidifier setting, refer to the attached microprocessor manual.

 The unit contains powered electric parts.
Before acceding to the inside parts, disconnect the unit from the power supply.



3.1 Electric parts

- 1 - Connection terminals: see the attached wiring diagram.
- 2 - Configuration microprocessor: it is the component where the humidifier operating data are memorized.
- 3 - 2A fuses.
- 4 - TAM: amperometric transformer. Its function is to detect the humidifier absorbed current during the steam production phase.
- 5 - Combs: see the attached wiring diagram.

3.2 Dip-switch

- 6 - Dip-switch B: it is used for auxiliary functions and to set the automatic drainage time. It is set up from the manufacturer.
- 7 - Dip-switch A: it is used to set the alarm relay (usually closed) and the maximum steam production. It is set up from the manufacturer.
- 8 - TA rate: used to set TAM transformation rate. It is set up from the manufacturer.

3.3 Connectors

- 9 - It allows the connection to the serial interface RS485.
- 10 - It allows the connection to the remote display (if present)


3.4 Led

- 11 - Green: is switched on when the electronic card is powered correctly.
- 12 - Yellow: it is switched off when steam is not produced, while it is permanently switched on when at 100% of its nominal production. During the transitory production it winks at a frequency of 2 Hz. Once the nominal production is achieved it winks at a frequency of 0,5 Hz. A series of pulses is generated: each train of pulses is separated from the following train by means of a 3-seconds pause: by counting the number of pulses it is possible to determine the steam production in that moment.
- 13 - Red: in absence of alarms it is off; according to the type of alarm activated it emits short flashings (frequency of 2 Hz) or long flashings (frequency of 0,5 Hz); all trains of pulses are separated one from the other by a 3-seconds pause.


3.5 Digital terminals

- 14 - AB - AB remote ON-OFF activation.

3.6 Wiring diagram for single phase humidifier



3.7 Wiring diagram for three-phase humidifier



3.8 Types of alarms

TYPE	DESCRIPTION	RE-START (if what caused the alarm has been corrected)	RED LED	ALARM RELAY
Stop	The card stops the humidifier	Manual: to re-start, switch on and switch off the card	Alarm codes: each code is displayed in sequence.	SPST relay, usually closed according to DIP A setting. The relay action is cumulative: <ul style="list-style-type: none"> • The contact is open in presence of at least 1 alarm and AB-AB closed; • the contact is closed when: <ul style="list-style-type: none"> - all alarm causes have been eliminated; - all alarms have been cancelled, both manually and automatically, or when AB-AB is open**.
Disabled	The card stops the humidifier	- Automatic - Manual: to re-start, switch on and switch off the card or t send a reset order via RS485*.	Codes are displayed even if the alarm causes have been eliminated: to cancel the codes display, switch off and then switch on the card or send a reset order via RS 485	
Pre - alarm	The card does not stop the humidifier	automatic		

(*) Check in the following table the automatic-restart alarms and the manual-restart alarms.

(**) Not all alarms are associated to the relay (check the following table)

3.9 Alarms description

Red LED flashings	Description and possible causes	Corrective action	Alarm		
			Type	Reset	Alarm relays
2 short flashings	Overcurrent at the electrodes: 1. water conductivity too high (usually when the unit restarts after a short stop) 2. high water level caused by a drain valve malfunction 3. high water level caused by a fill valve leakage 4. electrodes malfunction	1. drain some water and re-start 2. check the discharge valve operates properly 3. check possible leakage of the fill valve when not energised	stop	manual	active
3 short flashings	No current at the electrodes: when the humidifier is on, no steam is produced	1. check the external control signal: type (V or mA)? Value?Connections? 2. switch off the unit and disconnect the internal connections	stop	manual	active
4 short flashings	Internal memory error	1. download the appropriate configuration by means of Humiset 2. if the problem persists, contact CAREL customer service	stop	manual	active
5 short flashings	High supply water conductivity	1. check the threshold set with the parameter via RS485 2. switch off the unit and clean the conductivity probe electrodes 3. if the problem persists, change the supply water source or install a suitable treatment system (demineralisation, even only partially) N.B.: the problem cannot be solved by softening the supply water .	stop	manual	active
2 long flashings	Cylinder depleted	Perform the maintenance and/or replace the cylinder	signal	manual	Not affected
3 long flashings	No supply water	1. make sure the charge pipe to the humidifier and the internal pipe are not blocked or bended and supply pressure is sufficient (0.1/0.8 MPa) 2. Check the fill valve operates properly 3. check the counter pressure in steam outlet hose does not exceed the maximum limit, preventing the supply water from flowing into the cylinder by gravity 4. check the steam outlet hose is not clogged and there is no condensate	disabled	manual	active
4 long flashings	Excessive reduction in production	Cylinder completely depleted or excessive foam. Carry out the cylinder maintenance.	disabled	manual	active
5 long flashings	Drain malfunctioning	Check the drain circuit and the correct operation of the drain valve	disabled	manual	active
6 long flashings	User parameters error	1. download the appropriate configuration by means of Humiset 2. if the problem persists, contact CAREL customer service	stop	manual	active
7 long flashings	Pre-alarm of high water supply conductivity	1. check the water supply conductivity 2. check the limit set by parameter b5 via RS485 3. if needed, install an appropriate demineralisation system N.B.: the problem cannot be solved by softening the supply water.	signal	Display, automatic reset	Not affected
8 long flashings	Control signal not correctly connected (only 0/10V)	1. check the connection to the external controller 2. check the setting of parameters A0 and A2 via RS485	disabled	Alarm: Automatic Display: manual	active
9 long flashings	Full cylinder with no production	With the humidifier OFF: 1. check between the fill valve filaments and the condensate return pipe 2. check the level sensors are clean	disabled	manual	active
10 long flashings	Foam	Foam is generally caused by surface-active agents container in water (lubricants, solvents, detergents, agents for water treatment, softeners) or by an excessive concentration of dissolved salts: 1. drain and clean the supply water pipes 2. clean the cylinder 3. check the presence of softeners (in this case employ a different type of supply water or reduce the softening)	signal	Display, manual reset	not affected
11 long flashings	Cylinder almost completely depleted	Carry out the maintenance and/or replace the cylinder	signal	Display, manual reset	Not affected
RS 485	Hour counter error	Switch off the humidifier and make sure there is no defective electric connection or damage, then clear the hour counter via RS485	signal	only via RS485	Not affected

4 - GENERAL MAINTENANCE



The routine maintenance operations refer to the steam cylinder replacement and to the yearly unit cleaning.



Before starting any maintenance operation, disconnect the humidifier power supply.

4.1 Steam cylinder replacement

This operation is necessary when the electrodes active surface is so encrusted as to impede a sufficient current flow. When this situation occurs, an alarm is activated from the control card.



The cylinder might be hot. Leave it cool down before touching it or wear gauntlets.

How often this operation must be done depends on the supply water quality and on the operating conditions. Anyway, it is recommended to replace the cylinder at least every 5 years or after 10,000 hours of operation.

To replace the cylinder, it is necessary to:

- Ø Drain completely the water contained into the cylinder;
- Ø Disconnect the unit power supply by means of the main switch or the line fuses;
- Ø Take the steam pipe off the cylinder;
- Ø Disconnect the electric connections on main electrodes and take the plugs off the level electrodes;
- Ø Unblock the cylinder from the fixing system and lift it to remove it;
- Ø Install the new cylinder on the humidifier, performing the previous operations in reverse order.

4.2 Periodical checks

After one hour of operation:

- Ø Make sure there is no significant water leakage.

Every 15 days or no more than 300 operating hours:

- Ø Check operation, the absence of significant water leaks, the general humidifier conditions. Make sure during operation there is no arc or spark between the electrodes.

Every three months or no more than 1000 operating hours:

- Ø Check operation, the absence of significant water leaks, and replace the cylinder if necessary.



In case of leakage, disconnect the humidifier from the power supply before touching the cylinder.

4.3 Unit cleaning

The unit must be checked and cleaned yearly. It is advisable to do it in summer when the unit stops working.



Do not employ detergents or solvents to clean plastic components.



Descaling washings can be carried out with a solution containing 20% of vinegar or acetic acid, then rinse with water.

After taking the boiler cylinder off, the following operations must be performed:

- Ø After disconnecting the wirings and the pipes, remove the fill solenoid valve and check if the inlet filter needs any cleaning. If needed, wash the filter with water and a soft brush.
- Ø Remove the drain pump and check there are no deposits in the cylinder connection and remove, if it is the case, the impurities. Make sure the O-ring seal is not damaged or cracked and replace it if necessary.
- Ø Disconnect the drain valve from the power supply, unscrew the collector, remove the coil and dismantle the valve body, remove any impurities and rinse with water.
- Ø Make sure there are no clogging up or solid particles in the fill tank and check the conductivity electrodes are clean; remove any impurities and rinse with water.
- Ø Check the inlet supply water pipes, the fill water pipes and the overflow pipes. No debris must be present. If it is the case, remove them and rinse with water.



After replacing or checking the hydraulic parts, check the connections have been carried out correctly. Re-start the unit and execute a number of fill and drain cycles (from 2 to 4). Once the cycles are completed, check there are no water leaks by employing the safety procedure.



When stopping the unit for a certain period, empty the steam cylinder completely.

5 - TROUBLESHOOTING

TROUBLE	POSSIBLE CAUSE	CORRECTIVE ACTION
Humidifier cannot start	No power supply	check the protection upstream the humidifier and check if there is power supply
	Controller connectors are not plugged correctly	make sure the connectors are plugged properly in the terminal board
	Fuses interrupted	check fuses F1/F2/F3
	Damaged transformer	check that on secondary side of transformer there are 24 VAC
Humidifier does not work	Remote ON/OFF contact open (relay/terminals AB- AB) on control CP4	close ON/OFF contacts (relay/terminals AB- AB) on control CP4
	Control signal not compatible with the set signal	make sure the external signal is 0-10V
Humidifier fills water without producing steam	Too high counter pressure into steam outlet hose	check the steam outlet hose has no bending or choking
	Clogged inlet cylinder filter	clean the filter
	Limestone deposit in the fill tank	wash the fill tank
	Malfunctioning of the drain electrovalve	check if any irregular presence of 24 Vac on drain electrovalve and/or replace the drain electrovalve
The line magnetothermic switch is activated	The magnetothermic switch is undersized	make sure the magnetothermic switch is oversized for a current value equivalent to at least 1,5 times the humidifier nominal current value
	Overcurrent at the electrodes	check the drain electrovalve operation, the fill electrovalve tightness when it is not excited, drain some water and restart.
Humidifier wets into the duct	The system is oversized	reduce the steam production set on the electronic card
Humidifier wets the floor	The supply hydraulic circuit or the overflow circuit is leaking	check the entire hydraulic circuit
	The steam outlet hose is not fixed properly to the cylinder	Check the steam outlet hose is well fixed



For troubles reported by the electronic card CP4 alarms, see par. 3.8

6 - DISMANTLING

The unit is made of plastic and metal parts.

Do not release these parts in the environment, but dispose them in compliance with local laws in force.

DICHIARAZIONE CE DI CONFORMITÀ EC DECLARATION OF CONFORMITY CE-KONFORMITÄTSERKLÄRUNG DECLARATION CE DE CONFORMITÉ

Il Fabbricante

The Manufacturer

Der Hersteller

Le Fabricant

EMICON A.C. S.P.A.
 via A. Volta, 49
 47014 Meldola (FC)
 tel. (+39) 0543/495611
 fax. (+39) 0543/495612
 e-mail emicon@emiconac.it

DICHIARA
che la macchina
DECLARES
that the machinery
ERKLÄRT
daß die Einheit
DECLARE
que l'unité
Modello
Model
Modell
Modèle
Matricola
Serial Nr.
Seriennr.
N.ro de série
è conforme a tutte le disposizioni pertinenti delle direttive
2004/108/EC
in quanto è stata progettata, costruita e collaudata in accordo con le seguenti Norme

EN 61000-6-1
EN 61000-6-2
EN 61000-6-3
EN 61000-6-4

fulfils all the relevant provisions of the directives
2006/42/EC
because it has been designed, manufactured and tested according to the following Standards

EN ISO 12100-1
EN ISO 12100-2

den folgenden Vorschriften entspricht
da sie in Übereinstimmung mit den folgenden Normen geplant gebaut und getestet wurde
est conforme aux dispositions
2006/95/EC
étant l'appareil conçu, réalisé et testé dans le respect des normes suivantes

EN 60204-1
EN 60335-1
EN 60335-2-40
EN 60439-1


AUTORIZZA
a costituire il Fascicolo Tecnico.
AUTHORISES

Romano Santucci
 via A Volta, 49
 47014 Meldola (FC)

to compile its Technical File.
AUTORISIERT
die technischen Unterlagen zu erstellen
AUTORISE
à réaliser le dossier technique.

Meldola, ___/___/_____

Romano Santucci



Technical Manager

EMICON A.C. S.p.a. – Via A. Volta, 49 – 47014 Meldola (FC) Italy – P.IVA IT 03402390409

Reg. Imprese di Forlì-Cesena n. 03402390409 – REA n. 299199

Capitale sociale € 800.000,00 i.v.

 Tel. (39) 0543 495611 – Fax (39) 0543 495612 – E-mail: emiconac@emiconac.it

Emicon A.C. S.p.a. reserves the right to make changes to tis products without any prior notice.



Emicon A.C. S.p.a. Via A.Volta 49 Meldola Tel. +39 0543 495611 Fax +39 0543 495612